

**WI-FI SMART POWER STRIP**

**1. SETTING MINIMUM SPEED**

This WiFi smart Power Strip is provided with two-year after-sale service since the date of purchasing.

If you have any questions while operating the product or the Power Strip is defective, or the Power Strip cannot connect with the WiFi, please feel free to contact the service mail. We will help you solve the problems.

Tips:

1.1 This WiFi Smart Power Strip can only support 2.4G network and cannot work with 5.0G network, please check if your home network is 2.4G and make sure that your phone has been connected to your WiFi home work at the time of connecting the device with the phone.

1.2 Please disconnect the device from power while there is lightening, whenever possible.


**2. PRODUCT INFORMATION**

Rated Input	: 250 V~, 50/60 Hz
Outlet Rating	: 13 A (Max)
USB Port Output	: 5 V 4.2 A
Power Consumption at idle state	: <0.7 W
Mounting Center Distance	: 160 mm
Warranty Period	: 2 years
Materials	: Polycarbonate, nylon (flame retardant), stainless steel, brass
Supported Wireless Protocols	: Bluetooth, Wi-Fi 2.4 GHz
Compatible Mobile Apps	: OrelHome, Tuya Smart
Coverage	: 30 m (line of site)
Plug	: 13 A fused plug top
Input Wire	: 3 m (3x1.5 mm <sup>2</sup> cable)
Dimensions	: 320x80x40 (mm)
Colour	: Matte black
Applications	: Residential, hotel, general purpose

**3. USING THE SMART POWER STRIP**

On the main control page, you can :

- A. Turn on/off all the plug sockets.
- B. Turn on/off individual plug sockets.
- C. Change the smart power board settings.
- D. Rename the plug sockets.
- E. Access the options menu.



**4. DOWNLOAD & INSTALL THE APP**

- 4.1 Search "Smart Dialog Home" App in App Store or Google Play Store and install the app
- 4.2 Input account name and password to log in. If you don't have an account, please register an account with email address or mobile number.



**5. ADD NEW DEVICE**

**Device Preparation**

5.1 Press and hold the master button on the power strip until the light flashes.

**In app operation**

- 5.2 Connect your phone to local Wi-Fi
- 5.3 Tap "+" icon in the upper right corner of the app to add new device. Then, choose the corresponding device
- 5.4 Follow the app instructions to complete the adding process.

**6. HOW TO CHANGE WIFI FROM 5.0 TO 2.4 Hz?**

It is recommended that you log in to the router's background to select the router's frequency mode, open the router management page (usually on the label on the bottom of the router marked with the address of the management page), select the 2.4 GHz.

**7. TROUBLESHOOTING TIPS**

Please check whether the device is connected with power and your phone is connected with WiFi.

Check routers : If the router is dual-band router, please select a 2.4 GHz network to add device.

If you have bought several switches and find that they can't connect at the same time, maybe is the WiFi router can't support enough devices. Try to add another router or reduce the WiFi connection of other smart products.

Press the master button to switch on/off all four sockets at the same time, if the WiFi connectivity is not available.